

Programming Quick Guide

-DC9257A: Docking Scanner


-DC9267A: Wearable Scanner

Docking Scanner:

Gently tap the trigger area at the middle of scanner, to enable the scanner (for reading barcode)

Wearable Scanner:

Press the ring trigger to enable the scanner.



The touch sensor area is around middle of the scanner as drawing shown.



Installation

They are Plug & Play USB (HID) devices. When plugged into your Android OTG devices, it can be recognized as barcode scanner and begin to scan the barcode. Before using scanner, make sure the smartphone or tablet is fully charged. Open your APP, they can work as a keyboard input.


Reset Configuration to Defaults

If you are unsure of the scanner configuration or have scanned the incorrect codes, please scan the "Default" barcode. This will reset the scanner to its factory defaults. (scan from 1 to 7)




Barcode Configuration Method:

(Flow chart for setup procedure :)




Keyboard Language (For USB HID only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | \$ # { } [] = / ' \ < > ~




1D Symbolgies – 1



Barcode Configuration Method:

(Flow chart for setup procedure :)



1D Symbologies – 2

ENABLE 	<u>MSI</u>	DISABLE
ENABLE 	<u>EAN-8</u>	DISABLE
ENABLE 	<u>EAN-13</u>	DISABLE
ENABLE 	<u>UPC-E</u>	DISABLE

1D Symbologies – 3

ENABLE 	<u>UPC-A</u>	DISABLE
ENABLE 	<u>Interleaved 25</u>	DISABLE
ENABLE 	<u>Matrix 25</u>	DISABLE
ENABLE 	<u>Industrial 25</u>	DISABLE
ENABLE 	<u>CODE 93</u>	DISABLE
ENABLE 	<u>CODABAR</u>	DISABLE
ENABLE 	<u>CODE 128</u>	DISABLE
ENABLE 	<u>GS1-128 UCC/EAN-128</u>	DISABLE
ENABLE 	<u>GS1-Databar (RSS)</u>	DISABLE

1D Symbologies – 4

ENABLE 	<u>GS1-Databar (RSS-Limited)</u>	DISABLE
ENABLE 	<u>GS1-Databar (RSS-Expand)</u>	DISABLE
ENABLE 	<u>ISSN</u>	DISABLE
ENABLE 	<u>ISBN</u>	DISABLE

Inter-Keystroke Delay (FOR USB HID Only)

This parameter specifies the delay between emulated keystrokes

No Delay 	Short Delay (5ms)
Medium Delay (10ms) 	Long Delay (15ms)

● Information in this document is subject to change without notice.