

Programming Quick Guide


- DC9257L: Docking Scanner
- DC9267L: Wearable Scanner

Docking Scanner:

Gently tap the trigger area at the middle of scanner, to enable the scanner(for reading barcode)

Wearable Scanner:

Press the ring trigger to enable the scanner.



The touch sensor area is around middle of the scanner as drawing shown.

Installation

They are Plug & Play USB (HID) devices. When plugged into your Android OTG devices, it can be recognized as barcode scanner and begin to scan the barcode. Before using scanner, make sure the smartphone or tablet is fully charged. Open your APP, they can work as a keyboard input.


Reset Configuration to Default

(scan from 1 to 3)



Barcode Configuration Method:

(Flow chart for setup procedure :)



Keyboard Country (For USB HID only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | \$ # { } [] = / ' \ < > ~



Keyboard Country (For USB HID only)

Scan the appropriate country code as below to program the keyboard layout for your country or language. As a general rule, the following characters are supported, but need special care for countries other than the United States: @ | \$ # { } [] = / ' \ < > ~



1D Symbolgies – 1



UPC-E



UPC-A



Code 128




GS1-128
UCC/EAN-128




Barcode Configuration Method:


(Flow chart for setup procedure :)




1D Symbologies – 2



1D Symbologies – 3



2D Symbologies



How to put trigger cable into plastic buckle:




1. plastic wire buckle of DC9267A



2. press the plastic buckle and pull backward




3. release the lock



4. make sure the lock is released



5. put trigger cable into plastic buckle



6. push plastic buckle to make it locked.

- Information in this document is subject to change without notice.
- For more information, please visit:
www.riotec.com.tw

R_180717_01